



- 1. Wear flame resistant clothing.
- 2. Wear leather boots.
- Wear a welding helmet (ANSI Z87 Lens), welding gloves and safety glasses (ANSI Z87).
- 4. Make sure the area is well ventilated and use protective masks if needed.
- 5. Don't look at the welding arcs flame.
- 6. Remove any clutter from the work area.
- 7. Always have a fire extinguisher near-by.
- 8. Make sure the power cord, ground, and leads are in good condition.
- 9. Be sure you avoid standing in or having contact with water while operating a welder.
- 10. Remove all flammable material and gases from the area.
- 11. Always inspect your welds.



For more information, contact TOIRMA at (888) 562-7861 CLAIM REPORTING HOTLINE (844) 562-2720 | Available 24/7

